



Whirlpool® 31-inch Wide All Refrigerator with LED Lighting - 18 cu. ft.

WRR56X18FW

Available Finishes/Colours

☐ WRR56X18FW
White

You'll have plenty of room to store all your favorites inside this 18 cu. ft. ENERGY STAR® certified all refrigerator. Choose the ideal temperature for whatever foods you're storing with convenient electronic temperature controls and humidity-controlled crispers.

Top Features

LED Interior Lighting

Electronic Temperature Controls

Manuals & Literature:

 [Dimension Guide](#)  [Energy Guide](#)

 [Owners Manual](#)  [Warranty Information](#)

Dimensions		Refrigerator Compartment	
Depth	30.0	Spill Proof Glass Shelves	
Height	66.75	Non Climate Control Drawers	
Width	30.25	Door Bins	
Specifications		Dispenser	
Product To Product Pairs		Dispenser Type	N/A
Fingerprint Resistant	No	Controls	
Extended Service Plan Parent	EW06IW1Y, EW06IW2Y, EW06IW4Y	Control Lockout	N/A
Optional Accessories	W10346771A, W11462816	Electrical	
Country Of Origin	USA	Volts	115.0
Refrigerator Compartment		Amps	15.0
Temperature Controlled Drawers		Compatibility	
Supplementary Containers		Works With	
		Connectivity	

PRODUCT MODEL NUMBERS


WRF57R18D WSR57R18D
WRR56X18F

Recommended grounding method

A 115 Volt, 60 Hz., AC only, 15- or 20-amp fused, grounded electrical supply is required. It is recommended that a separate circuit serving only your freezer be provided. Use an outlet that cannot be turned off by a switch. Do not use an extension cord.


NOTE: Before performing any type of installation, cleaning, or removing a light bulb, turn the control (Thermostat, Refrigerator or Freezer Control depending on the model) to OFF and then disconnect the refrigerator from the electrical source. When you are finished, reconnect the refrigerator to the electrical source and reset the control (Thermostat, Refrigerator or Freezer Control depending on the model) to the desired setting. See "Using the Controls."

PRODUCT DIMENSIONS



Model Number	Model Size	Door Swing	Height - Overall "A"	Height - Top of Cabinet "B"	Depth - Door Open 90° "C"	Depth - With Handles "D"	Depth - Without Handles "E"	Depth - Cabinet Only "F"	Width - Cabinet "G"
WRF57R18D WRR56X18F	17.7 cu. ft.	Right	66 ³ / ₄ " (169.5 cm)	66 ¹ / ₄ " (168.3 cm)	55 ⁷ / ₈ " (141.9 cm)	30" (76.2 cm)	29 ¹ / ₈ " (74 cm)	24 ⁵ / ₈ " (62.5 cm)	30 ¹ / ₄ " (76.8 cm)
WSR57R18D	17.7 cu. ft.	Right	66 ³ / ₄ " (169.5 cm)	66 ¹ / ₄ " (168.3 cm)	55 ³ / ₄ " (141.6 cm)	31 ¹ / ₄ " (79.4 cm)	28 ⁷ / ₈ " (73.3 cm)	24 ⁵ / ₈ " (62.5 cm)	30 ¹ / ₄ " (76.8 cm)

LOCATION REQUIREMENTS



Ventilation and Clearance

- This freezer may be installed side by side with another refrigerator or freezer. Allow at least 1" (2.54 cm) between back of cabinet and the wall, and a 1/4" (6.4 mm) clearance between the appliances.
- If you are installing your refrigerator next to a fixed wall, leave extra space on the hinge side so the door can open wider.
- Keep flammable materials and vapors, such as gasoline, away from freezer.
- Do not cover the freezer with items such as blankets, sheets, tablecloths, etc. This reduces air circulation.

Temperature

Your freezer operates most efficiently when located in an area where the temperature will not fall below 40°F (5°C). Place your freezer in a location where the temperature will not fall below this recommended temperature.