



Lush washable area rug

Your new Lush washable area rug is made from 100% Polyester that has an incredibly soft touch.

It is a one-piece machine washable rug and low pile with lightweight making it extremely easy to maintain .

Washing instructions :

Place your area rug in the washing machine with cold water on gentle cycle (Do Not Use Bleach)

We recommend line drying your rug or dry without heat on the air-only drying cycle.

The minimum Washing machine size for a 5'x8' rug (or bigger) is a 4.2+ Cu.Ft.

You can also clean spills immediately by blotting with a clean sponge or cloth.

A soft TPR non-slip backing is integrated that will help avoid slipping and sliding as well as protecting your floor from stains and scratches.

It is highly recommend to also use a rug pad to add comfort, extend the life of your rug and provide more protection.

Rugs may contain temporary creases upon arrival, this is normal.

Gently smooth them out with your hands, flatten them on the floor and walk around, allow time for creases to flatten and settle. You may also tightly roll you rug in the opposite direction and leave it for a couple days then unroll it.

Vacuum regularly without the use of a rotary brush and on low intensity.

Shaking your area rug will also help getting rid of dirt and dust efficiently. Rotate your rug from time to time to avoid pre-mature wear on a same area.



Tapis décoratif Lush Lavable à la machine

Votre nouveau tapis lavable Lush est fabriqué à partir de 100 % polyester qui a un toucher incroyablement doux.

Il s'agit d'un tapis lavable en machine et à poils ras avec un poids léger ce qui le rend extrêmement facile à entretenir.

Instructions de lavage :

Placez votre tapis dans la machine à laver avec de l'eau froide en cycle délicat (ne pas utiliser d'eau de Javel)

Nous vous recommandons de sécher votre tapis sur une corde ou de le sécher sans chaleur à l'air uniquement cycle de séchage.

La taille minimale de la machine à laver pour un tapis de 5'x8' (ou plus) est de 4.2+ Cu.Ft.

Vous pouvez également nettoyer immédiatement les déversements en éponge ou en chiffon propre.

Un support antidérapant en TPR souple est intégré qui aidera à éviter de glisser et de glisser également pour protéger votre sol des taches et des rayures.

Il est fortement recommandé d'utiliser également un sous-tapis pour ajouter du confort, prolonger la durée de vie de votre tapis et fournir plus de protection.

Les tapis peuvent contenir des plis temporaires à l'arrivée, c'est normal.

Lissez-les doucement avec vos mains, aplatissez-les sur le sol et marchez

Autour, laissez le temps aux plis de s'aplatir et de se déposer. Vous pouvez également rouler fermement Tapis dans la direction opposée et laissez-le pendant quelques jours puis déroulez-le.

Passer l'aspirateur régulièrement sans utiliser de brosse rotative et à faible intensité.

Secouer votre tapis aidera également à vous débarrasser efficacement de la saleté et de la poussière.

Faites pivoter votre tapis de temps en temps pour éviter une usure prématurée au même endroit.