

# Congélateur vertical Whirlpool® de 20 pi³ avec avertisseur de température

WZF79R20DW

**Finis/couleurs disponibles**

WZF79R20DW
Blanc

Mettez en lumière vos aliments congelés favoris dans ce congélateur vertical de 20 pi³ doté d'un éclairage intérieur à DEL. En activant la fonction de congélation rapide, la température s'abaisse rapidement pour sceller la fraîcheur et la saveur des aliments. L'avertisseur de température vous avertit si la température des alimentsest trop élevée. Ce congélateur vertical prévient l'accumulation de givre pour assurer un dégivrage sans complications. Les commandes de température électroniques vous permettent de choisir la température idéale pour tous les types d'aliments congelés. En outre, vous serez certain de ne jamais manquer de glaçons grâce à la machineà glaçons en option.

## Caractéristiques clés

**Éclairage intérieur à DEL**

**Congélation rapide**

**Commande de température électronique**

**Guides et documentation:**

Guide des dimensions

Guide énergétique

Guides d'installation

Renseignements sur la garantie

## Dimensions

| | |
|---|---|
| Profondeur | 29.13 |
| Hauteur | 60.75 |
| Largeur | 33.25 |

## Compartiment du congélateur

| | |
|---|---|
| Tablettes | 4 réglables, pleine largeur, clayette |
| Éclairage | Oui |
| Description du panier | 1 Panier de fil profond; 1 Panier en fil métallique peu profond |
| Nombre de tablettes de congélateur | 4 |

## Fiche technique

| | |
|---|---|
| UPC | 883049341545 |
| Programmes de service d'entretien autorisés | EW05IW1Y, EW05IW2Y, EW05IW4Y |

## Fiche technique

| | |
|---|---|
| Modèles associés | |
| Bill 29 | 6 |
| Accessoires en option | W11729596 |
| Fabriqué en | USA |

## Commandes

| | |
|---|---|
| Mode Sabbat | 15.8 F à -15.3 F (-9.3 C à -26.3C) |
| Type de dégivrage | Dégivrage automatique |
| Avertisseur de surveillance de la température | Oui |
| Avertisseur de porte ouverte ou entrouverte | Oui |

Étant donné que la politique de Whirlpool Canada LP comprend un engagement continu dans l'amélioration de ses produits, nous nous réservons le droit de modifier les matériaux et les fiches techniques sans préavis. Les dimensions sont à des fins de planification uniquement. Pour des informations complètes, veuillez vous référer aux instructions d'installation fournies avec le produit. Les spécifications peuvent être modifiés sans préavis.

# Upright Freezer

## PRODUCT MODEL NUMBERS

WZF56R16D
WZF79R18D
WZF79R20D
WZF57R16F


**Recommended grounding method**
A 115 Volt, 60 Hz., AC only, 15- or 20-amp fused, grounded electrical supply is required. It is recommended that a separate circuit serving only your freezer be provided. Use an outlet that cannot be turned off by a switch. Do not use an extension cord.

**NOTE:** Before performing any type of installation, cleaning, or removing a light bulb, turn the control (Thermostat, Refrigerator or Freezer Control depending on the model) to OFF and then disconnect the refrigerator from the electrical source. When you are finished, reconnect the refrigerator to the electrical source and reset the control (Thermostat, Refrigerator or Freezer Control depending on the model) to the desired setting. See “Using the Controls.”

**Water Pressure**
A cold water supply with water pressure of between 30 and 120 psi (207 to 827 kPa) is required to operate the water dispenser and ice maker.


**Reverse Osmosis Water Supply**
The pressure of the water supply coming out of a reverse osmosis system going to the water inlet valve of the freezer needs to be between 30 and 120 psi (207 and 827 kPa).

## PRODUCT DIMENSIONS




| Model Number | Door Swing | Model Size | Height - Overall “A” | Height - Top of Cabinet “B” | Depth - Door Open 90° “C” | Depth - With Handles “D” | Depth - Without Handles “E” | Depth - Cabinet Only “F” | Width - Cabinet “G” |
|---|---|---|---|---|---|---|---|---|---|
| WZF56R16D | Right | 15.7 cu. ft. | 60¾" (154.3 cm) | 60¼" (153.0 cm) | 55⅞" (141.9 cm) | 30¼" (76.8 cm) | 29⅛" (74.0 cm) | 24⅝" (62.5 cm) | 30¼" (76.8 cm) |
| WZF79R18D | Right | 17.7 cu. ft | 66¾" (169.5 cm) | 66¼" (168.3 cm) | 55⅞" (141.9 cm) | 30" (76.2 cm) | 29⅛" (74.0 cm) | 28" (71.1 cm) | 30¼" (76.8 cm) |
| WZF79R20D | Right | 19.6 cu. ft | 66¾" (169.5 cm) | 66¼" (168.3 cm) | 58⅞" (149.5 cm) | 30" (76.2 cm) | 29⅛" (74.0 cm) | 28" (71.1 cm) | 33¼" (84.5 cm) |
| WZF57R16F | Right | 16 cu. ft | 60¾" (154.3 cm) | 60¼" (153.0 cm) | 55⅞" (141.9 cm) | 30¼" (76.8 cm) | 29⅛" (74.0 cm) | 24⅝" (62.5 cm) | 34" (86.3 cm) |

## LOCATION REQUIREMENTS




**Ventilation and Clearance**

- Allow at least 3" (7.5 cm) of air space at the top and on both sides of the freezer. Allow at least 1" (2.54 cm) between back of cabinet and the wall.
- If you are installing your refrigerator next to a fixed wall, leave extra space on the hinge side so the door can open wider.
- Keep flammable materials and vapors, such as gasolline, away from freezer.
- Do not cover the freezer with items such as blankets, sheets, tablecloths, etc. This reduces air circulation.

**Temperature**
Your freezer operates most efficiently when located in an area where the temperature will not fall below 40°F (5°C). Place your freezer in a location where the temperature will not fall below this recommended temperature.

Because Whirlpool Corporation policy includes a continuous commitment to improve our products, we reserve the right to change materials and specifications without notice.

Dimensions are for planning purposes only. For complete details, see Installation Instructions packed with product. Specifications subject to change without notice.

Ref. W10668404B
5/16